















 <p>18-0779 HEAD COVER Replaces: 6G5-11193-A0-00</p>	 <p>18-0781 HEAD COVER Replaces: 6E5-11193-A0-00</p>	 <p>18-0815 HEAD COVER Replaces: 6H4-11193-A1-00</p>	 <p>18-0821 COVER Replaces: 6J8-12414-A0-00</p>	
 <p>18-0239 AP# 2020 WEAR PLATE TO PUMP HOUSING Replaces: 688-44315-A0-00</p>	 <p>18-0240 AP# 2022 WEAR PLATE TO GEAR CASE MOUNTING Replaces: 688-44316-A0-00</p>	 <p>18-0244 AP# 2052 WEAR PLATE TO WATER PUMP Replaces: 6E5-44315-A0-00</p>	 <p>18-0292 WEAR PLATE TO PUMP HOUSING Replaces: 663-44315-A0-00</p>	
 <p>18-0294 WEAR PLATE TO PUMP BASE Replaces: 663-44324-A0-00</p>	 <p>18-0756 AP# 2330 WATER PUMP Replaces: 6H3-44315-A0-00</p>	 <p>18-0757 AP# 2331 OUTER PLATE Replaces: 6H3-44324-A0-00</p>	<p>PKG. OF 2</p>  <p>18-0768 WEAR PLATE Replaces: 682-44315-A0-00</p>	
 <p>18-0773 AP# 2316 WEAR PLATE Replaces: 689-44316-A0-00</p>	 <p>18-0747 WATER SEAL DAMPER Replaces: 22-44367-00-00</p>	 <p>18-0826 AP# 2232 40-90 HP PLUG Replaces: 90430-14115-00-00</p>	 <p>18-0814 AP# 2217 SEAL Replaces: 6H3-14457-01-00</p>	 <p>18-4274 AP# 1831 SPACER Replaces: 688-45997-01-00</p>

OUTBOARD