



IGNITION PRESTOLITE DISTRIBUTOR PARTS GUIDE

PRESTOLITE DISTRIBUTOR PARTS GUIDE						
Distributor Number	Contact Set	Condenser ③	Rotor	Cap	Ignition Coil	Tune-Up Kit
IAD-6004-2F, 2N, 2P	18-5307	18-5340	—	—	18-5435 ①	—
IAO-4109-1M	18-5307	18-5340	18-5430	18-5392	18-5435 ①	—
IAO-4113-1M	18-5307	18-5340	18-5430	18-5392	18-5435 ①	—
IAO-4114-1M	18-5307	18-5340	18-5430	18-5392	18-5435 ①	—
IAY-4010, A	18-5307	18-5340	18-5427	18-5355	18-5435 ①	—
IAY-4014	18-5307	—	18-5427	18-5355	18-5435 ①	—
IAY-4014C	18-5307	18-5340	18-5427	18-5355	18-5435 ①	—
IBB-4205	18-5303 ②	—	18-5407	—	18-5435 ①	—
IBB-4301B	18-5303 ②	18-5340	18-5407	18-5369	18-5434	18-5255 ⑦
IBB-7003	18-5303 ②	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-4106	18-5303	18-5340	18-5407	18-5369	—	18-5255 ⑦
IBM-4107, A	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-4108, A, B, C	18-5303	18-5340	18-5407	18-5369	—	18-5255 ⑦
IBM-4109, A	18-5303	18-5340	18-5407	18-5369	—	18-5255 ⑦
IBM-4110	18-5303	18-5340	18-5429	18-5391	—	18-5259
IBM-4112	18-5303	18-5340	18-5429	18-5391	18-5435 ①	18-5259
IBM-4115	18-5303	18-5340	18-5429	18-5391	18-5435	18-5258
IBM-4116	18-5303	18-5340	18-5429	18-5391	18-5435	18-5258
IBM-4117A	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-4118A	18-5303	18-5340	18-5429	18-5391	18-5435 ①	18-5259
IBM-4119, A	18-5303	18-5340	18-5429	18-5391	18-5435 ①	18-5259
IBM-4120	18-5303	18-5347	18-5429	18-5391	18-5434	18-5259
IBM-4122	18-5303	18-5347	18-5407	18-5369	18-5435 ①	18-5258 ⑦
IBM-7003B, BS	18-5303	18-5340	18-5407	18-5369	18-5434	18-5255 ⑦
IBM-7004A, AS, B, BS	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-7007, A, AS, S	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-7008, A, AS, B, BS, C, CS, S	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-7010	—	18-5340	18-5407	18-5369	18-5434	—
IBM-7011	18-5303	18-5340	18-5407	18-5369	18-5434	18-5255 ⑦
IBM-7011A	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-7011B	—	18-5340	18-5407	18-5369	18-5435 ①	—
IBM-7011C, D	18-5303	18-5340	18-5407	18-5369	18-5435 ①	18-5255 ⑦
IBM-7013	18-5303	18-5340	18-5403	18-5352	—	18-5262 ④
IBM-7013A	18-5303	18-5340	18-5403	18-5352	18-5434	18-5262 ④
IBM-7013B	—	18-5340	18-5403	18-5352	—	—
IBM-7013C, D, E	18-5303	18-5340	18-5403	18-5352	—	18-5262 ④
IBM-7014	18-5303	18-5340	18-5403	18-5353	—	18-5262 ⑥
IBM-7014A	18-5303	18-5347	18-5403	18-5353	18-5434	18-5258 ⑥
IBM-7016	18-5303	18-5340	18-5409	18-5352	—	18-5260 ④
IBM-7017	18-5303	18-5340	18-5409	18-5352	—	18-5260 ④
IBM-7018	18-5303	18-5340	18-5409	18-5353	—	18-5260 ④
IBM-7019, A, AS, S	18-5303	18-5340	18-5403	18-5352	18-5435 ①	18-5262 ④
IBM-7020, A, AS, B, BS, C, CS, S	18-5303	18-5340	18-5403	18-5352	18-5435 ①	18-5262 ④
IBM-7021	18-5303	18-5340	18-5403	18-5353	—	18-5262
IBP-4105, A	—	18-5340	18-5407	18-5369	18-5435 ①	—
IBP-4110, A, B	—	18-5340	18-5429	18-5391	18-5435 ①	—
IBP-4111A	—	18-5340	18-5407	18-5369	18-5435 ①	—
IBP-4112A, B	—	18-5340	18-5429	18-5391	18-5435 ①	—
IBP-4113A, B, C	—	18-5340	18-5429	18-5391	18-5435 ①	—
IBR-4205, A, S	—	18-5347	—	—	18-5435 ①	—
IBR-7002, A, AS, S	18-5307	18-5340	18-5430	18-5392	18-5434	—
IDD-7001	N/A	N/A	18-5407	18-5369	—	N/A
IDH-7001, S	N/A	N/A	18-5407	18-5369	—	N/A
IDH-7002, S	N/A	N/A	18-5407	18-5369	—	N/A
IDH-7003, A, AS, S	N/A	N/A	18-5407	18-5369	—	N/A
IDH-7004	N/A	N/A	18-5409	18-5352	—	N/A
IDH-7005	N/A	N/A	18-5409	18-5352	—	N/A
IDH-7006, A	N/A	N/A	18-5403	18-5352	—	N/A
IDH-7802	N/A	N/A	18-5403	—	18-5433	N/A
IDU-7601	N/A	N/A	18-5403	18-5353	—	N/A
IDU-7801, A, B	N/A	N/A	18-5403	18-5352	18-5433	N/A
IGC-5501A	18-5307	18-5340	18-5430	—	18-5435 ①	—
IGW-4056	—	—	—	—	18-5434	—
IGW-4118A	—	—	—	—	18-5435 ①	—
IGW-4199B, C	—	—	—	—	18-5435 ①	—
IGW-4301	—	—	—	—	18-5435 ①	—
IGW-4409A	—	—	—	—	18-5435 ①	—

N/A Not Applicable ① 12 Volt System Only ② 2 Required ③ Condensers 18-5340 (Wire Conductor) and 18-5347 (Strap Conductor) are interchangeable.
 ④ 18-5275 Kit with distributor cap ⑥ 18-5276 Kit with distributor cap ⑦ 18-5277 Kit with distributor cap